## Dynasty 350 and 700

#### **TIG/Stick Welding Power Source**



## **Quick Specs**



#### **Industrial Applications**

**Precision Fabrication** Heavy Fabrication Pipe and Tube Fabrication Aerospace Aluminum Ship Repair **Anodized Aluminum Fabrication** 

#### **Processes**

TIG (GTAW) Pulsed TIG (GTAW-P) Stick (SMAW) Air Carbon Arc (CAC-A)

**350:** 1/4-in. maximum **700:** 3/8-in. maximum Input Power 208-575 V, 3- or 1-Phase Power

3-350 A Amperage Range 350:

700: 5-700 A

**Rated Output** 350: 300 A at 32 V, 60% Duty Cycle

700: 600 A at 44 V, 60% Duty Cycle

350: 135 lb. (61 kg) Weight

700: 198 lb. (90 kg)



Allows for any input voltage hookup (208-575 V) with no manual linking, providing convenience in any job setting. Ideal solution for dirty or unreliable power.

Meter calibration allows meters to be calibrated for certification.

120-volt auxiliary power receptacle for cooling system or small tools.

Wind Tunnel Technology™ protects internal electrical components from airborne contaminants, extending the product life.

**Fan-On-Demand**<sup>™</sup> power source cooling system operates only when needed, reducing noise, energy use and the amount of contaminants pulled though the machine.

Blue Lightning™ high-frequency arc starter for more consistent non-contact starts and greater reliability compared to traditional HF arc starters.

**Lift-Arc**<sup>™</sup> start provides AC or DC arc starting without the use of high frequency.

Program memory features nine independent program memories that maintain/save your parameters.

Auto-postflow calculates the length of postflow time based on the amperage setting. This eliminates the need to independently set the postflow time for different amperages. This feature preserves your tungsten and prevents porosity.



**Dynasty 350 Complete Package** with Wireless Foot Control

#### Stick Features (AC/DC)

Tailored arc control (DIG) allows the arc characteristic to be changed for specific applications and electrodes. Smooth running 7018 or stiffer, more penetrating 6010.

**Hot Start**<sup>™</sup> adaptive control provides positive arc starts without sticking.

AC frequency control adds additional stability when Stick welding in AC for smoother welds.



Power source is warranted for 3 years, parts and labor.

#### **AC TIG Features**

Independent amplitude/amperage control allows EP and EN amperages to be set independently to precisely control heat input to the work and electrode.

**Extended AC balance** (30–99%) controls the amount of oxide cleaning (amperage time in EP) which is essential for high quality welds on aluminum.

AC frequency (20-400 Hz) controls the width of the arc cone and the force of the arc.

#### **AC Waveforms**

\_\_\_\_ Advance squarewave, fast freezing puddle, deep penetration and fast travel speeds.

Soft squarewave for a soft buttery arc with maximum puddle control and good wetting action.

Sine wave for customers that like a traditional arc. Quiet with good wetting.

\_\_\_\_ Triangular wave reduces the heat input and is good on thin aluminum. Fast travel speeds.

#### **DC TIG Features**

**Exceptionally smooth** and precise arc for welding exotic materials.

High-speed DC TIG pulse controls. Pulse frequency capable of pulsing 5000 pulses per second. Pulsing adds arc stability, reduces heat input and warpage and can increase travel speeds. Other parameters include peak amperage, peak time and background amperage.



#### Miller Electric Mfg. Co.

An ITW Company 1635 West Spencer Street P.O. Box 1079 Appleton, WI 54912-1079 USA

#### **Equipment Sales US and Canada**

Phone: 866-931-9730 FAX: 800-637-2315 International Phone: 920-735-4554 International FAX: 920-735-4125

#### MillerWelds.com







## **Specifications** (Subject to change without notice.)










Model	Input Power	Welding Amperage Range	Rated Output	Amps 208 V	Input at 230 V	Rated I	oad Ou 460 V	tput, 50 575 V	)/60 Hz KVA	KW	Max. Open-Circuit Voltage	Dimensions	Net Weight
Dynasty 350	Three- Phase	3-350 A	250 A at 30 V, 100% Duty Cycle	29	26	15	13	10	10.3	9.9	75 VDC 10-15 VDC*	W: 13.75 in. (349 mm)	135.5 lb. (61 kg)
			300 A at 32 V, 60% Duty Cycle	35	32	18	16	13	12.7	12.1		D: 22 in. (559 mm)  with TIGRunner®  H: 43.125 in. (1146 mm)  W: 23.125 in. (587 mm)	with TIGRunner® 308 lb.
	Single- Phase	3-350 A	180 A at 27.2 V, 100% Duty Cycle	35	32	_	15	12	7.4	6.8			
			225 A at 29 V, 60% Duty Cycle	47	43	_	21	17	9.8	9.1		D: 43.75 in. (1111 mm)	(140 kg)
Dynasty 700	Three- 5- Phase	5-700 A	500 A at 40 V, 100% Duty Cycle	75	68	39	34	27	27	26	75 VDC 10-15 VDC*	H: 34.5 in. (876 mm) W: 13.75 in. (349 mm)	198 lb. (90 kg)
			600 A at 44 V, 60% Duty Cycle	97	88	51	44	35	35	34		D: 22 in. (559 mm) with TIGRunner®	with
	Single- Phase	5-700 A	360 A at 34 V, 100% Duty Cycle	82	74	_	37	30	17	16		H: 53.125 in. (1400 mm) W: 23.125 in. (587 mm)	370 lb.
			450 A at 38 V, 60% Duty Cycle	115	104	_	52	42	24	22		D: 43.75 in. (1111 mm)	(168 kg)

© Certified by Canadian Standards Association to both the Canadian and U.S. Standards. CE models conform to the applicable parts of the IEC 60974 series of standards.

\*Indicates sense-voltage for Lift-Arc™ TIG and Low OCV Stick.

## **Control Panel**



#### **Control Panel Parameter Values**

1. Memory	36 Combinations	6. Sequencer Contro	I
-	(9 AC TIG)	Initial Amps	Dynasty 350: 3-350 A
	(9 AC Stick)		Dynasty 700: 5-700 A
	(9 DC TIG)	Initial Slope	0.0-50.0 seconds
	(9 DC Stick)	Final Slope	0.0-50.0 seconds
2. Polarity	AC/DC	Final Amps	Dynasty 350: 3-350 A
3. Process/	TIG: HF Impulse, Lift Arc		Dynasty 700: 5-700 A
Arc Starting	STICK: Adaptive Hot Start	7. Gas/DIG Preflow	0.0-25.0 seconds
4. Output Control	Standard Remote,	Postflow	Auto Postflow,
	2T Trigger Hold, Output ON		Adjust 0.0 – 50 seconds
5. Pulser Control		DIG	0-100%
	nd DC: 0.1-5000 PPS	8. AC Waveshape	
. a.ooo po. oooo	AC: 0.1-500 PPS	EN Amperage	3-350 A/5-700 A
Peak Time	5-95%	EP Amperage	3-350 A/5-700 A
Background Am	ps 5-95%	Balance	30-99%
•	•	AC Frequency	20-400 Hz

- 9. Amperage Control
- 10. Encoder Control
- 11. Ammeter Display
- 12. Voltmeter Display
- 13. Memory Display

#### **Additional Setup Parameter Values**

**Preprogrammed Starts** 

Dynasty 350 .020-3/16 in. tungsten Dynasty 700 .040-1/4 in. tungsten

**Programmable Starts** 

Amperage Dynasty 350: 3 – 200 A
Dynasty 700: 5 – 200 A
Time 0 – 200 milliseconds
Ramp Time 0 – 250 milliseconds

Minimum Amperage Dynasty 350: 3 – 25 A Dynasty 700: 5 – 25 A

Additional Triggers 3T, 4T, Mini Logic,

4T Momentary

Waveshapes Advance Squarewave,

Soft Squarewave, Sine Wave, Triangular wave

Amplitude Lock EN EP Same,

EN EP Independent

**Spot/Weld Timer** 0.0 – 999 seconds

**OCV** Low OCV, Normal OCV

Stick Stuck Check On/Off

**Lockouts** Four levels **Arc Timer** 0.0-9999 hours

and 0-59 minutes

±0-20.0 volts



## **Performance Data**

#### **DUTY CYCLE**

# Dynasty 350 3-PHASE % AMPERAGE 30% 350 A 60% 300 A

250 A

Dynas	Dynasty 700				
3-PHASE					
% AMPERAGE					
30%	700 A				
60%	600 A				
100%	500 A				

1-Pł	IASE
%	AMPERAGE
10%	350 A
30%	250 A
60%	225 A
100%	180 A

100%

1-PH	IASE
%	AMPERAGE
10%	700 A
30%	500 A
60%	450 A
100%	360 A

## **TIG Upgrade Chart**

## Which Machine is Right for You?

Why Upgrade?	Syncrowave 350		Dynasty 350	Dynasty 350 Benefits
Maximum Thickness Capacity	1/2-in. Aluminum	UPGRADE	5/8-in. Aluminum	Increases aluminum thickness.
High Frequency Arc Starting	Continuous HF	UPGRADE	Start Only	Start Only limits HF interference issues.
Frequency Control AC Output Control	Fixed at 60 Hz	UPGRADE	Variable 20-400 Hz	Higher frequencies provide better arc control and faster travel speeds.
AC Waveforms	Soft Squarewave	UPGRADE	Advanced Squarewave Soft Squarewave	Advanced Squarewave =Travel faster
				Soft Squarewave = Maximum puddle control
			Sine Wave Triangular Wave	Sine Wave = Traditional characteristics
			$\longrightarrow$	Triangular Wave = Reduced heat input
Weld Aluminum with Pointed Tungsten		UPGRADE		Waveshaping controls maintain the point. The benefits are: reduced heat input into your part, smaller weld beads, better starting and more control of the arc.
Portability	496 lb. Manual Links 208/230/460 V Single-Phase	UPGRADE	135 lb. Auto-Line™ 208-575 V Single-Phase or Three-Phase	Easier to move because of size and weight. Auto-Line™ allows the unit to operate on any voltage. Single- or three-phase. Even generators!
Power Draw at 300 Amps	110 A at 230 V Single-Phase	UPGRADE	32 A at 230 V Three-Phase	Power requirement to operate is much less. Smaller electrical service needed, smaller breaker/fuses and power cord.
Precise Controls	Some Digital Controls	UPGRADE	All Digital Controls	Accuracy and repeatability with all digital controls.



## **AC Waveshape Controls**


#### **Feature** Waveform **Effect on Bead Effect on Appearance** Reduces balling Narrow bead, with no **AC Balance Control** 51 - 99% EN visible cleaning action and helps Controls arc cleaning action. Adjusting the maintain point Amperage **0** % EP % EN of the AC wave controls the width of Bead the etching zone surrounding the weld. % EN Note: Set the AC Balance control for adequate arc cleaning action at the sides and in front of the weld No Visible Cleaning puddle. AC Balance should be fine tuned according to how heavy or thick the oxides are. 30 - 50% EN Wider bead and Increases balling cleaning action action of the electrode Amperage **0** % EP Bead % EN Cleaning 60 Cycles per Second Wider bead. Wider bead and **AC Frequency Control** good penetration cleaning action Controls the width of the arc cone. Increasing ideal for buildup work Amperage % **EP** the AC Frequency provides a more focused arc with increased directional control. Bead % EN Note: Decreasing the AC Frequency softens the arc and broadens the weld puddle for a wider weld bead. Cleaning 120 Cycles per Second Narrower bead and Narrower bead for cleaning action fillet welds and automated applications Amperage 0 Bead % EN % EN Cleaning Narrow bead, with no More current in **Independent AC Amperage Control** visible cleaning EN than EP: Allows the EN and EP amperage values to be Deeper penetration Current set independently. Adjusts the ratio of EN to 0 and faster travel EP amperage to precisely control heat input ENspeeds Bead to the work and the electrode. EN amperage controls the level of penetration, while EP No Visible Cleaning amperage dramatically effects the arc cleaning action along with the AC Balance control. Wider bead and More current cleaning action in EP than EN: EP+ Shallower Current 0 penetration Bead Cleaning



## **AC Waveshape Controls (Continued)**

#### AC Waveform Selection


Select from four different AC waveforms to optimize the arc characteristic for your application. Choose from:



#### **Pulse TIG Controls**

#### **High Speed DC TIG-Pulse Controls**

- PPS Pulses per second (Hz): DC = 0.1-5,000 PPS / AC = 0.1-500 PPS
- % **ON** % **Peak Time:** 5-95% (Controls the amount of time during each pulse cycle at the PEAK amperage.)
- Background Amps: 5-99% (Sets the low-pulse amperage value as a % of the Peak Amps.)





automation where maximum travel speeds are required.

## Dynasty 350 and 700 Models/Packages







Machine Only		Water-Cooled (Machine/Cart/Cooler)	Water-Cooled Complete Packages (Machine/Cart/Cooler/Torch Kit/Remote)		
Model		TIGRunner®	Foot Control Complete	Wireless Foot Control Complete	
Dynasty 350 (CSA) #907 204		#907 204-00-1	#951 401	#951 402	
Dynasty 350 (CE) #907 204-02-1		_	_	_	
Dynasty 700 (CSA) #907 101		#907 101-00-1	#951 403 #951 404		
Dynasty 700 (CE)	#907 101-02-1	_	_	_	
Dynasty 700 (CE) #907 101-02-1  Comes with:  • 8-ft. primary cord (350 model)  • Setup video and quick-reference guide  • Two Dinse 50-mm connectors (350 model)  • Two thread-lock connectors (700 model)  • One thread-lock water-cooled adapter (700 model)		Comes with:  • 8-ft. primary cord (350 model)  • Setup video and quick-reference guide  • Runner Cart #300 244  • Coolmate 3.5 #300 245	Comes with:  • 8-ft. primary cord (350 model)  • Setup video and quick-reference guide  • Runner Cart #300 244  • Coolmate 3.5 #300 245 and Coolant (4 gal.) #043 810  • 300 A Water-Cooled Torch Kit #300 183 (350 model) or  400 A Water-Cooled Torch Kit #300 186 (700 model)  • Remote Control #194 744 (Foot) or  Remote Control #300 429 (Wireless Foot)		

#### Four Easy Steps to Create Your Own Package (Select desired stock number for each step.)



## **Genuine Miller® Accessories**

#### **Torch Kits**

#### 250 A Water-Cooled Torch Kit #300 185

- 25-foot (7.6 m) Weldcraft® WP20 torch with Dinse
- Torch cable cover
- AK4C torch accessory kit includes shielding cups, collets, collet bodies and 2% ceriated tungsten electrodes (1/16, 3/32 and 1/8 inch)
- Regulator/flowmeter HM2051A-580
- Gas hose (regulator to machine)
- 15-foot (4.6 m) 1/0 weld lead with clamp (work or ground lead) and Dinse connector

#### 310 A Water-Cooled Torch Kit #300 183

Recommended for Dynasty 350

- 25-foot (7.6 m) Weldcraft® CS310 torch with Dinse
- Torch cable cover
- CS310AKC torch accessory kit includes shielding cups, collets, collet bodies and 2% ceriated tungsten electrodes (1/16, 3/32 and 1/8 inch)
- Regulator/flowmeter HM2051A-580
- Gas hose (regulator to machine)
- 15-foot (4.6 m) 1/0 weld lead with clamp (work or ground lead) and Dinse connector

## **400 A Water-Cooled Torch Kit** #300 186 Recommended for Dynasty 700

- 25-foot (7.6 m) Weldcraft® WP18SC torch with thread-lock
- Torch cable cover
- AK18C torch accessory kit includes shielding cups, collets, collet bodies and 2% ceriated tungsten electrodes (3/32, 1/8 and 5/32 inch)
- Regulator/flowmeter H1954D-580
- Gas hose (regulator to machine)
- 12-foot (3.7 m) 4/0 weld lead with clamp (work or ground lead)



### Genuine Miller Accessories (Continued)

#### **Remote Controls and Switches**



#### Wireless Remote Foot Control #300 429

For remote current and contactor control. Receiver plugs directly into the 14-pin receptacle of Miller

machine. 90-foot (27.4 m) operating range.



#### Wireless Remote Hand Control #300 430

For remote current and contactor control. Receiver plugs directly into the 14-pin receptacle of Miller

machine. 300-foot (91.4 m) operating range.



#### RCCS-14 Remote Contactor and Current Control #043 688

North/south rotary-motion fingertip control fastens to TIG torch using two Velcro® straps. Includes 26.5-foot (8 m) cord and 14-pin plug.



#### RCC-14 Remote Contactor and Current Control #151 086

East/west rotary-motion fingertip control fastens to TIG torch using two Velcro® straps. Includes 26.5-foot (8 m) cord and 14-pin plug.

#### RFCS-14 HD Foot Control #194 744

Maximum flexibility is accomplished with a reconfigurable cord that can exit the front, back or either side of the pedal. Foot pedal provides remote current and contactor control. Includes 20-foot (6 m) cord and 14-pin plug.



#### RHC-14 Hand Control #242 211 020

Miniature hand control for remote current and contactor control. Dimensions: 4 x 4 x 3.25 inches (102 x 102 x 83 mm).

Includes 20-foot (6 m) cord and 14-pin plug.



#### RMLS-14 Switch #129 337

Momentary- and

maintained-contact rocker switch for contactor control. Push forward for maintained contact and backward for momentary contact. Includes 26.5-foot (8 m) cord and 14-pin plug.



## RMS-14 On/Off Control #187 208

Momentary-contact switch for contactor control. Rubber-covered pushbutton dome switch ideal for repetitive on-off applications. Includes 26.5-foot (8 m) cord and 14-pin plug.

#### Extension Cables for 14-Pin Remote Controls

**#242 208 025** 25 ft. (7.6 m) **#242 208 050** 50 ft. (15.2 m) **#242 208 080** 80 ft. (24.4 m)



#### Runner Cart #300 244

Designed to accommodate Dynasty® or Maxstar® 350 or 700 power sources and a Coolmate® 3.5 Cooler. Cart features single cylinder rack, foot pedal holder, three cable/torch holders, and two TIG electrode filler holders.



#### Coolmate™ 3.5 #300 245

Designed to integrate with the Dynasty® and Maxstar® 350 and 700 power

sources. For use with water-cooled torches rated up to 600 amps. 3.5 gallon capacity.

#### Low-Conductivity TIG Coolant #043 810

Sold in multiples of four in one-gallon recyclable plastic bottles. Miller coolants contains a base of ethylene glycol and deionized water to protect against freezing to -37° Fahrenheit (-38° C) or boiling to 227° Fahrenheit (108° C).



#### Water-Cooled Dinse Torch Adapter #195 377

For Dynasty and Maxstar 350. Used to adapt WP20, WP18, and CS310 to Dinse-style connector.



#### Water-Cooled Thread-Lock Torch Adapter #225 028

For Dynasty and Maxstar 700. Used with (WP125, WP24W, WP25, WP20, WP18, WP12, CS310,

CS410, WP22, WP27) water-cooled torch.

#### Automation Interface Connection Kit #195 516 Field

Provides control of power source welding parameters through a 28-pin receptacle. The 28-pin receptacle replaces the standard 14-pin receptacle and requires a PLC controller to operate the power source. Ideal for automated equipment integration.

#### Weld Current Sensor #300 179 Field

Detects when work clamp is not connected and prevents expensive damage to disconnect devices and input power cord and wiring.

#### **Educational Materials**

To order, please call Miller Literature at 866-931-9732 or visit MillerWelds.com/resources/tools.

Gas Tungsten Arc Welding (TIG) Publication #250 833

Simulator and Setup CD-ROM #233 558

#### DVD Setup Video #251 116

Video topics include tungsten selection, setup menus, DC pulse, sequencer, balance and frequency settings. (Included with machine.)

#### **TIG Welding Gloves**



Industrial TIG
Welding Gloves
#249 199 Large
#249 200 X-Large
Unlined pigskin leather palm
with reinforced palm patch.



TIG Welding Gloves #249 178 Medium #249 179 Large #249 180 X-Large Durable goatskin back and palm with flame-resistant cotton fleece back.



TIG Welding Gloves (Short Cuff) #249 181 Medium #249 182 Large #249 183 X-Large Durable pigskin back and goatskin palm with 3-inch cuff.

## **Tungsten**

Tungsten	Amp Range	2% Ceriated (AC/DC)	2% Lanthanated (AC/DC)
1/16 in. (1.6 mm)	70-150 A	WC116X7	WL2116X7
3/32 in. (2.4 mm)	140-250 A	WC332X7	WL2332X7
1/8 in. (3.2 mm)	225 – 400 A	WC018X7	WL2018X7
5/32 in. (4.0 mm)	300-500 A	WC532X7	WL2532X7



## **Ordering Information**

Equipment and Options	Stock No.	Description	Qty.	Price
Dynasty® 350	#907 204	Auto-Line™ 208 – 575 VAC, 50/60 Hz, <b>CSA</b> . 8-ft. primary cord		
Dynasty® 350 TIGRunner®	#907 204-00-1	Auto-Line™ 208 – 575 VAC, 50/60 Hz, <b>CSA</b> . 8-ft. primary cord. <i>Requires coolant</i>		
Dynasty® 350 Complete with Wireless Remote Foot Control	#951 402	Auto-Line™ 208 – 575 VAC, 50/60 Hz, <b>CSA</b> . 8-ft. primary cord		
Dynasty® 350 Complete with Foot Control	#951 401	Auto-Line™ 208 – 575 VAC, 50/60 Hz, <b>CSA.</b> 8-ft. primary cord		-
Dynasty® 350 International	#907 204-02-1	Auto-Line <sup>™</sup> 380 – 575 VAC, 50/60 Hz, <b>CE.</b> 8-ft. primary cord		-
Dynasty® 700	#907 101	Auto-Line™ 208 – 575 VAC, 50/60 Hz, <b>CSA</b>		
Dynasty® 700 TIGRunner®	#907 101-00-1	Auto-Line 200 – 273 VAC, 50/60 Hz, <b>CSA.</b> Requires coolant		
Dynasty® 700 Complete	#951 404	Auto-Line 200 373 VAC, 50/60 Hz, <b>CSA</b> Auto-Line™ 208 – 575 VAC, 50/60 Hz, <b>CSA</b>		
with Wireless Remote Foot Control	#331 404	Auto-Eilie 200 – 373 VAO, 30/00 112, <b>33A</b>		
Dynasty® 700 Complete with Foot Control	#951 403	Auto-Line™ 208 – 575 VAC, 50/60 Hz, <b>CSA</b>		
Dynasty® 700 International	#907 101-02-1	Auto-Line™ 380 – 575 VAC, 50/60 Hz, <b>CE</b>		
TIG Torch Kits				
Weldcraft® Water-Cooled Torch Kits	#300 185	250 A, WP-20 Kit. See page 6		
	#300 183	310 A, CS310 Kit. See page 6. Recommended for Dynasty 350		
W. I	#300 186	400 A, WP18SC Kit. See page 6. Recommended for Dynasty 700		
Weldcraft® 200 A Air-Cooled Torch	#WP2625RM	For Dynasty 350 only. Adapter #195 379 required		+
Remote Controls				
Wireless Remote Foot Control	#300 429	Foot control with wireless 90-ft. (27.4 m) operating range		
Wireless Remote Hand Control	#300 430	Hand control with wireless 300-ft. (91.4 m) operating range		
RCCS-14	#043 688	North/south fingertip control		
RCC-14	#151 086	East/west fingertip control		
RFCS-14 HD	#194 744	Heavy-duty foot control		
RHC-14	#242 211 020	Hand control		
RMLS-14	#129 337	Momentary/maintained rocker switch		
RMS-14	#187 208	Momentary rubber dome switch		
Extension Cables		See page 7		
Accessories				
Runner™ Cart	#300 244	See page 7		
Coolmate™ 3.5	#300 245	115 VAC, 50/60 Hz, <b>CE</b> . Requires coolant		
ΓΙG Coolant	#043 810	Sold in multiples of four in one-gallon plastic bottles		
Automation Interface Kit	#195 516	Field. Provides required automation connections		
Weld Current Sensor	#300 179	Field. Installation required		
Torch Adapters		Supplied with torch kits		
Water-Cooled Dinse Torch Adapter	#195 377	Used to connect water-cooled torch to Dinse terminal machine. For WP20, WP18 and CS310 (adapter included in torch kit)		
Water-Cooled Thread-Lock Torch Adapter	#225 028	Used to connect water-cooled torch to Dynasty/Maxstar 700 (adapter included with 700 models)		
Cable Connectors		Supplied with power source and torch kits		
Dinse Connector 50 mm (1 male)	#042 418	Used to connect weld lead to Dinse terminal machine		
Thread-Lock Connectors (2 male)	#225 029	Used to connect weld lead to Dynasty 700 or Maxstar 700		
Dinse Connector 50 mm (1 male, 1 female)	#042 419	Used to extend weld cables		
Tweco® Terminal Adapter	#042 465	Male Dinse to female Tweco		
Cam-Lok Terminal Adapter	#042 466	Male Dinse to female Cam-Lok		
Gas Tungsten Arc Welding (TIG) Publication	#250 833	To order, call Miller Literature at 966, 021, 0722		
Simulator and Setup CD-ROM	#233 558	To order, call Miller Literature at 866-931-9732 or visit MillerWelds.com/resources/tools		
DVD Setup Video (included with machine)	#251 116	OI VISIL WIIIIGI VVGIUS.COIII//1630U1063/10013		
Tungsten		See page 7		
TIG Welding Gloves		See page 7		
Consumables, Cylinder, Hose and Fittings				

Date: Total Quoted Price:

Distributed by:

